

03-081

TRAILER HITCH

WILL FIT CLUB CAR® DS®

INSTALLATION INSTRUCTIONS

INCLUDED:

Trailer Hitch Hardware Pack TOOLS NEEDED:

17mm Socket 17mm Wrench



We recommend professional installation. If you choose to not have this product installed by a professional, we highly recommend that you exercise caution, care, and patience when installing this product as it involves drilling holes into your cart's body.

Engage Parking Brake and chock wheels. Place RUN/TOW switch in TOW position. Remove four factory bolts on the bumper and retain.









Remove factory bumper.

Mount trailer hitch to cross member as shown using supplied hardware. Tighten hardware.





Using hardware retained from Step 1, attach bumper. Retained hardware should mount down from bumper through trailer hitch. Tighten hardware.

Insert hitch into receiver and secure with pin.



INSTALLATION COMPLETE