



PART#04-041

# INNER BASKET FOR E-Z-GO® TXT®


## INSTALLATION INSTRUCTIONS

### INCLUDED:

- (1) Basket
- (2) Brackets
- Hardware Pack
- (2) 8mmx40mm Bolts
- (4) 8mm Flat Washers
- (2) 8mm Nylock Nuts
- (4) 6mmx18mm Bolts
- (8) 6mm Flat Washers
- (4) 6mm Nylock Nuts

### TOOLS NEEDED:


- 5/16" Drill Bit
- Drill
- 13mm Socket
- 14mm Wrench
- 10mm Socket
- 10mm Wrench
- Torpedo Level
- (2) C-Clamps



We recommend professional installation. If you choose to not have this product installed by a professional, we highly recommend that you exercise caution, care, and patience when installing this product as it involves drilling holes into your cart's body.

Install basket mounts to basket using 6mm bolts, washers and nuts supplied in hardware pack and secure.

1



2  
Clamp basket and mounts to front struts approximately 1" above top of dash or desired location and level.



3  
Drill hole through strut and secure using supplied 8mmx40mm bolts, washers and nuts.



**INSTALLATION COMPLETE**